




real flame

Leaders in
Gas Fireplace
Technology



CAPTIVA ISLAND® BALANCED FLUE SPACE HEATER

INSTALLATION & OPERATING MANUAL

The Captiva Island gas fire is approved to be installed as a zero clearance firebox and are designed to operate on Natural Gas and Propane (LPG) gases ONLY.
Approval Number GMK10060.

VERSION 9

WARRANTY INFORMATION

The benefits provided to you under the following warranty are in addition to any other rights and remedies available to you under the law.

1. Warranty

If:

- (a) during the first 10 years from the date of purchase (Firebox Warranty Period), there is a defect in the firebox of the Real Flame Gas Burner; or
- (b) during the first 12 months from the date of purchase (Parts Warranty Period), there is a defect in the gas valves or other parts of the Real Flame Gas Burner,
due to improper workmanship or material, Real Flame will replace or repair the Real Flame Gas Burner without charge. Any replacement product is warranted only for the time remaining on the original Firebox Warranty Period or the Parts Warranty Period as relevant.

2. Registration

You must register to receive the benefit of this warranty by completing the warranty registration on our website (www.realflame.com.au) or completing and mailing the attached registration card within 30 days of purchase of your Real Flame Gas Burner (or, if the Real Flame Gas Burner is fitted to a new home, within 30 days of the date of settlement of purchase of such new home).

3. Exclusions

Real Flame is not obliged to replace or repair the Real Flame Gas Burner under clause 1 if:

- (a) it has been improperly stored, installed, connected, used, operated or repaired, or damaged, abused, tampered with, altered (without our written approval), or not maintained in strict accordance with our installation and operating instructions; or
- (b) it has been installed in an outdoor setting.

4. Limit of Liability

The warranty provided under this warranty is limited to replacement or repair of the Real Flame Gas Burner only, at our option. To the extent permitted by law, Real Flame excludes liability for consequential loss or any other loss or damage caused to property or persons arising from any cause whatsoever, and damage arising from normal wear and tear.

5. Claiming under the Warranty

In order to claim under this warranty you must, within the Firebox Warranty Period or the Parts Warranty Period (as relevant), contact Real Flame, providing the original proof of purchase and the details below:

Supplier Name _____

Date Of Purchase / settlement of property if new home _____

Model / Serial Number _____

This warranty does not cover the cost of claiming under the warranty or transporting the Real Flame Gas Burner to and from the supplier.

Our goods come with guarantees that cannot be excluded under the Australian Consumer Law. You are entitled to a replacement or refund for a major failure and for compensation for any other reasonably foreseeable loss or damage. You are also entitled to have the goods repaired or replaced if the goods fail to be of acceptable quality and the failure does not amount to a major failure.

If you would like to speak to someone about your Real Flame Gas Burner or claiming under this warranty, please contact the Real Flame Service Warranty Desk on 03 8706 2000.

Real Flame Pty Ltd ACN 006 311 155

Head Office: 1340 Ferntree Gully Road, Scoresby 3179

Telephone: 03 8706 2000 Facsimile: 03 8706 2001

WARNING

The “Captiva Island” has a primary safety glass fitted in front of the inner glass panels. This safety glass is fitted to the appliance to reduce the risk of injury from burns and at no time should this glass be permanently removed. NOT INTENDED FOR FIREPLACE INSERT.

For protection of young children or the infirm, a secondary guard is required.

INSTALLATION NOTICE

- The installation of this appliance is only to be carried out by an authorised person in accordance with the Manufacturer’s Instructions, local gas fitting regulations, AS5601-2004 installation code for gas burning appliances and any other relevant statutory regulations.
- In all cases the installation of this appliance shall meet the requirements as set out in AS5601-2004.

- NOTE: A slight smell may be apparent for the first few hours of use. This is due to the heat resistant paint curing. It is recommended to open windows in the room for the first lighting of the fire. In some instances a slight discolouration may occur inside the firebox. This is a normal condition and is not covered by warranty.
- This heater is designed to have a luminous flame and may exhibit a slight carbon deposit.

IMPORTANT SAFETY NOTICE

- DO NOT PLACE ARTICLES ON OR AGAINST THIS APPLIANCE.
- DO NOT USE OR STORE FLAMMABLE MATERIAL NEAR THE APPLIANCE.
- DO NOT SPRAY AEROSOLS IN THE VICINITY OF THIS APPLIANCE WHILST IT IS IN OPERATION.
- CARE MUST BE TAKEN TO ENSURE THAT ANY RETURN AIR REGISTER OR EXHAUST SYSTEM DOES NOT ADVERSLEY AFFECT THE OPERATION OF THE APPLIANCE OR DRAUGHT OF CHIMNEY OR FLUE.
- DO NOT MODIFY THIS APPLIANCE.
- DO NOT OPERATE WITH GLASS PANELS REMOVED FROM THIS APPLIANCE.

WARNING

The outer glass panel gets extremely hot! Precaution should be taken and young children supervised at all times when heater is operating.

CONTENTS

Contents	4
Data Plate	5
Zero Clearance introduction	6
Dimensions 2 sided	7
Dimensions 3 sided	8
Timber frame installation.....	9
Fluing options	11
Ceramic set up and installation procedures.....	12
Servicing and maintenance	14
Parts list	18
Flue termination (cowls) regulations	19
Remote control operating guide	20
Electrical diagram	23
Real Flame contact information	24

DATA PLATE (Affixed to the base of the unit for reference to gas pressure & consumption)

MODEL	CAPTIVA ISLAND	SERIAL NO.	DATE OF MANUFACTURE
GAS TYPE	APPROVAL: GMK10060		
NATURAL GAS @ 0.95 kPa Test Pressure Point (High)	Injector Size		Gas Consumption
	2 x 2.55 mm		43 Mj/hr
LPG @ 2.65 kPa Test Pressure Point (High)	Injector Size		Gas Consumption
	2 x 1.30 mm		43 Mj/hr
NATURAL GAS @ 0.50 kPa Test Pressure Point (Low)	Injector Size		Gas Consumption
	2 x 2.55 mm		33 Mj/hr
LPG @ 1.50 kPa Test Pressure Point (Low)	Injector Size		Gas Consumption
	2 x 1.30 mm		33 Mj/hr

CAPTIVA ISLAND ZERO CLEARANCE MODEL

INTRODUCTION

The Real Flame “Captiva Island” is a log/coal or pebble effect space heater for use with **Natural Gas and Propane**.

The Real Flame warranty will be voided by, and Real Flame disclaims any responsibility for the following actions:

- Modification of the space heater and/or components including balanced flue assembly or glass door.
- Use of any component part not manufactured or approved by Real Flame in combination with this “Captiva Island” fireplace system.
- Installation other than as instructed in this manual.

CAUTIONS

- Due to its high operating temperature, the appliance should be located out of traffic and away from furniture and draperies.
- Children and adults should be alerted to the hazards of the high surface temperature, which could cause burns or clothing ignition.
- Young children should be carefully supervised when they are in the same room as the appliance.
- Clothing or other flammable materials should not be placed on or near the appliance.

SELECTING YOUR APPLIANCE LOCATION

Your appliance may be installed in any location that is free of ducted return air vents or electrical wiring and plumbing. Safety, as well as efficiency of operation, must be considered when selecting the heater location. Try to select a location that does not interfere with room traffic, and offers access for the Balanced Flue terminal installation. Refer to AS5601-2004 for minimum clearances for Balanced Flue termination.


WARNING

When this appliance is installed directly on carpeting, tile or other combustible materials other than wood flooring, the appliance should be installed on a metal or wood panel extending the full width and depth of the appliance.


Should your heater exhibit abnormal operation, unusual flame, odours, excessive glass discolouration or failure to operate, please switch off and have the appliance serviced by a qualified personnel.

DIMENSIONS

Captiva Island 2 sided




Captiva Island 2 sided trim




DIMENSIONS

Captiva Island 3 sided



Captiva Island 3 sided trim




CAPTIVA ISLAND ZERO CLEARANCE MODEL (continued)

Captiva Island Zero Clearance Timber Frame Installation


Dimensions (in mm)

Model	A	B	C	D	E	F	G	H
2 sided	890	1100	560	715	805	210	470	210
3 sided	890	1100	560	715	805	210	470	210

2 sided




3 sided




Zero Clearance cowl types

- The Captiva Island balanced flue space heater is a zero clearance type heater which comes complete in a zero clearance casing.
- The flue can terminate horizontally or vertically.



**Vertical top
termination**




**Horizontal rear
termination**

Flue Size	Inner	Outer
2 sided	100mm	180mm
3 sided	100mm	180mm

CAPTIVA ISLAND FRAME DETAIL


Timber Frame Installation



Model	A	B	C*	D**
2 sided	1000	1225	560	600
3 sided	1000	1150	560	600

* Note: The "C" dimension is the finished depth including cladding.

**Note: The "D" dimension is the minimum required to allow room for the flue to exit the unit and fit a 90° elbow for vertical termination.



NOTE: Plasterboard to run
beyond stud as shown, and to
go behind trim.

Clearances from combustables


Floor	0 mm
Sides	50 mm
Top	100 mm
Flue Outer	50 mm

ISLAND ZERO CLEARANCE MODEL (continued)

INSTALLATION OF VERTICAL VENTING

Vertical terminations must be installed with the following clearances:

- Minimum of 500 mm from the nearest part of the roof (Measurement is taken from the bottom of the termination).
- Minimum of 1500 mm from any mechanical air inlet.
- Minimum of 500 mm from any building structure or obstruction facing the termination.
- Maximum vent height is 4.8 meters from the base of the unit.
- Minimum clearances 50mm from flue to all combustible materials must be maintained.
- 2 x 45° off sets allowed, must not exceed 25% of the height.
e.g. Typical vent installation of 4.8 meters from base of unit;
25% of 4.8 meters = 1.2 meters.



- Flue runs outside the above options must be checked with the manufacturer first.

HORIZONTAL FLUE TERMINATION LOCATION

This section is used to determine where your Balanced Flue termination will be located.:

- Flue terminations shall not be recessed in walls or sidings.
- **EXTREMELY IMPORTANT:** In heavy snow areas take extra care to prevent blocking flue termination with snow removal equipment.
- Flue gases exiting flue terminals are very hot and must not be restricted to assure fireplace combustion is not affected.
- Do not place, build any obstruction, plant any bushes or for any reason attempt to conceal the flue termination. To do so will affect the operation of the fireplace and may be hazardous.
- This unit must always vent directly to outdoors.

CAUTIONS AND REQUIREMENTS

All flueing must maintain a clearance of 50mm from combustible materials.

NOTE: It is imperative for satisfactory operation of the "Island" space heater that no flueing components be modified in any way. All components have been manufactured to eliminate the need for modification when properly selected and installed.

CAPTIVA ISLAND ZERO CLEARANCE MODEL (continued)

Captiva Island Fire Installation Procedure

- TICK BOXES
- ☐ Locate fire into frameout as per page 10
 - ☐ Connect to gas supply and check for leaks
 - ☐ Connect to power supply
 - ☐ Install flue as per directions on page 11
 - ☐ Plaster to unit with trims removed and then install trims
 - ☐ Test unit for safe operation and show customer correct operating procedure




Figure (1) Remove logs and coals from box and place supplied coals randomly around burner as shown. Do not cover burner rail.




Figure (2) Install logs A & B as shown.




Figure (3) Place logs A & B as shown in mirror image of logs A & B on opposite side.




Figure (4) Place logs C & D as shown, again logs C & D will be a mirror image.




Figure (5) Place log E on top as shown.

NOTE: There should be the following ceramics in the box:

- 2 x large side logs
- 2 x medium side logs
- 2 x curved centre logs
- 2 x tapered straight end logs
- 1 x top log
- 1 x packet small tapered coals (??)
- 1 x packet crescent shaped coals (6)
- 1 x packet square flat coals (12)

CAPTIVA ISLAND ZERO CLEARANCE MODEL (continued)

Captiva Island Fire Installation Procedure (continued)

PEBBLE OPTION

To install pebbles follow the instructions below taking care not to place the pebbles over the burner rail.




Figure (1) Place the 12 large pebbles into the burner as shown.




Figure (2) Add the 16 medium pebbles as shown.




Figure (3) Finally place the 32 small pebbles as shown.

NOTE: There should be 32 small pebbles, 16 medium pebbles and 12 large pebbles contained in the box.

SERVICING AND MAINTENANCE

IT IS RECOMMENDED THAT YOUR HEATER BE SERVICED AT LEAST EVERY TWO YEARS BY A QUALIFIED TRADESMAN.

- To follow when servicing, removing fan or changing valve or control modules.

IMPORTANT: POWER MUST BE ISOLATED PRIOR TO CARRYING OUT THE SERVICE/MAINTENANCE.

SERVICE/MAINTENANCE ONLY TO BE CARRIED OUT BY AN AUTHORISED PERSON.




Figure (1) To remove glass panel or panels, first remove the top louvre frames by removing the Allen screws.




Figure (2) Then loosen the louvres by loosening the screws at each end.




Figure (3) Once the louvres are loose you can remove the frames, and then take the louvre sets off.




Figure (4) Now loosen the outer glass holders whilst holding the glass.




Figure (5) Remove the outer glass.

SERVICING AND MAINTENANCE (continued)




Figure (6) Now remove the stainless steel corner section by removing two screws from top and two from bottom.




Figure (7) Loosen the top and bottom screws on the inner glass frames. Do end glass if 3 sided model.




Figure (8) Slide the inner glass out of the side and also the end if 3 sided model supplied.




Figure (9) Set up ceramics as per page 12 and 13.




Figure (10) To remove the remote control module, remove all wire connections and lift from double sided tape. Then remove module.




Figure (11) To remove the control module, disconnect wires and lift from double sided tape. Then remove module.

SERVICING AND MAINTENANCE (continued)




Figure (12) To remove the gas valve disconnect the main gas pipe from the left side and the burner pipe from the right.




Figure (13) Remove all wires and undo screws from both fixing brackets. Remove valve.




Figure (14) To remove the fan, undo the two screws from the bracket in front of the fan and remove bracket.




Figure (15) Remove the centre nut from the fan bracket and pivot the fan clockwise to clear the plenum chamber.




Figure (16) Remove the bottom curb and slide the fan out.




Figure (17) To remove burner, lift the burner surround and remove.

SERVICING AND MAINTENANCE (continued)




Figure (18) Undo the four fixing screws (one in each corner).




Figure (19) Tilt the burner up on support with a suitable block.




Figure (20) Undo the main burner nut.




Figure (21) Undo the pilot tube nut.




Figure (22) Disconnect the flame rod sensor and sparker leads.





Figure (23) Remove burner.

- After carrying out service or replacing parts, reverse the above processes to reinstate the components.
- Prior to lighting ensure there are no gas leaks.

If your Captiva Island fireplace still does not operate correctly, consult your dealer. All service and repairs should be performed by an authorised person or company. All spare parts and optional trim finishes are available from Real Flame Pty Ltd.

PARTS LIST



Gas Control Valve




Module Box



Remote Control Module




Remote Control




Sensor

GAS CONTROL ASSEMBLY



CAPTIVA ISLAND FLUE TERMINATION (COWLS) REGULATIONS

Balanced Flue



LEGEND:

<i>T</i> = Flue terminal	<i>M</i> = Gas meter	Shading indicates prohibited areas for flue terminals
<i>I</i> = Mechanical air inlet	<i>P</i> = Electricity meter or fuse box	

Ref.	Item	Minimum clearances (mm)	
		Natural draft	Fan assisted
a	Below eaves, balconies and other projections:		
	• Appliances up to 50 MJ/h input	300	200
	• Appliances over 50 MJ/h input	500	300
b	From the ground, above a balcony or other surface †	300	300
c	From a return wall or external corner †	500	300
d	From a gas meter (<i>M</i>) (see 4.7.11 for vent terminal location of <i>regulator</i>)	1000	1000
e	From an electricity meter or fuse box (<i>P</i>)	500	500
f	From a drain pipe or soil pipe	150	75
g	Horizontally from any building structure † or obstruction facing a terminal	500	500
h	From any other flue terminal, cowl, or combustion air intake †	500	300
j	Horizontally from an openable window, door, non-mechanical air inlet, or any other opening into a building with the exception of sub-floor ventilation:		
	• Appliances up to 150 MJ/h input	500	300
	• Appliances over 150 MJ/h input up to 200 MJ/h input	1500	300
	• Appliances over 200 MJ/h input up to 250 MJ/h input †	1500	500
	• Appliances over 250 MJ/h input †	1500	1500
	• All fan-assisted flue appliances, in the direction of discharge	-	1500
k	From a mechanical air inlet, including a spa blower	1500	1000
n	Vertically below an openable window, non-mechanical air inlet, or any other opening into a building with the exception of sub-floor ventilation:		
	• Space heaters up to 50 MJ/h input	150	150
	• Other appliances up to 50 MJ/h input	500	500
	• Appliances over 50 MJ/h input and up to 150 MJ/h input	1000	1000
	• Appliances over 150 MJ/h input	1500	1500

† Unless appliance is certified for closer installation

NOTES:

- All distances are measured to the nearest part of the terminal.
- Prohibited area below electricity meter or fuse box extends to ground level.
- See Clause 5.13.6.6 for restrictions on a flue terminal under a covered area.
- See Appendix J, Figures J2(a) and J3(a), for clearances required from a flue terminal to an LP Gas cylinder. A flue terminal is considered to be a source of ignition.
- For appliances not addressed above acceptance should be obtained from the technical regulator

REMOTE CONTROL OPERATING GUIDE

PLEASE REFER TO THE MILLENNIUM 7000 SERIES MANUAL ON OUR WEBSITE SHOULD YOU REQUIRE FURTHER DETAIL.

To assist service technicians who may not have access to this manual, the following is an abbreviated operating procedure. This should be read before servicing commences.

The Island 2 and 3 sided fires are controlled completely by the use of the remote control; this remote can be used either as a manual operation or an auto operation.

- The remote thermostat uses radio frequency to transmit to the gas/fan controller.
- The remote thermostat has a LCD display
- The remote thermostat uses 2 off "AA" batteries which should last for 12 months. (Depending on quality of battery.) Batteries should be changed when smoke alarms are changed.
- The remote control and the controller are non-serviceable parts and if faulty should be returned to Real Flame Pty Ltd for replacement.

Locating the remote

The remote houses the thermostat that controls the heat output of the fire. When storing the remote either on its wall bracket or by placing it somewhere in the room where the fire is located, ensure there are no other heat sources that will affect the thermostats ability to accurately read the room temperature. For example, by placing the remote in direct sunlight or under a cushion, the fire may turn down or off before the room reaches the set temperature.

Factory Set Features

- When turned on the fire will always start on the low setting and remain on low for 3 minutes, it will then go to the high setting.
- The fan will automatically come on in the high mode after the fire has been operating for 3 minutes 20 seconds.
- When the fire shuts off on auto mode or is shut off in manual mode, the fan will continue to operate for 3 minutes in the "High" mode.
- The fire can be operated in either "Auto" mode or "Manual" mode.

Setting the day and time

- Before changing settings the heater must be OFF. When in the OFF mode the only display shown on the remote is the room temperature and the time.
- To set the time press <T>, the hour will flash, set the correct hour by using the <UP> and <DOWN> button. When set, press <OK> to confirm.
- When the <OK> button is pushed the minutes will flash, again by using the <UP> and <DOWN> buttons set the correct minutes and then push the <OK> button.
- When the <OK> button is pushed the day will flash, again by using the <UP> and <DOWN> buttons set the correct day and then push the <OK> button.
- Your remote will now display the correct day and time.

To change settings


- The remote must be in the OFF mode to change settings. NOTE: Each of the 3 setting modes must be completed within 2 seconds.

To change between Degrees C to Degrees F

- Press in sequence <P>, <T>, <T>, <A/M>

To restore factory setting

- Press in sequence <P>, <T>, <T>, <DOWN>



REMOTE CONTROL OPERATING GUIDE (continued)

Teaching RF code

- Ensure the power to the heater is turned off.
- Press in sequence <P>, <T>, <T>, <UP>
- The LCD display will show “CL” (Code Learn) for 2 seconds then return to the normal OFF state display.
- During this time a special code will be transmitted by the RF thermostat to the control unit, causing the control unit to learn its ID.
- CAUTION: The thermostat has already been programmed with a unique code. Do not attempt to teach the RF thermostat ID code unless instructed by the manufacturer.

To program

- Press <P>
- “PD” will appear at the top of the display screen. And “MO” will flash.
- Press <OK>
- Time will flash and “P1” will appear in the screen.
- Set wake up time and press <OK> to confirm.
- Set temperature required and press <OK> to confirm.
- Repeat above steps for remaining “P2” (Away), “P3” (Coming Home) and “P4” (Sleep) programs.
- Repeat all of the above for each day.

When setting the programs have the remote near the unit to ensure the remote can communicate with the control (Located in the bottom of the heater.)

The Island will operate through the remote either in Manual Mode or Auto Mode, below is a sample of each:

Example of Manual Operation

Set the thermostat to desired Set temperature e.g. 26°C.

- The flame will start on low, with the fan off.
- After 3 minutes, the flame changes to the High setting, if the temperature is 23.5°C or lower. The fan will switch on High 3 minutes and 20 seconds after the flame is lit.
- As the temperature rises above 23.5°C, the modulating valve will decrease the gas level one step every 0.5° above 23.5°. The fan will continue to operate on High.
- When the room temperature reaches 26.5°C, the modulating valve will operate at its lowest setting. The fan will switch to Low speed.
- If the room temperature were to rise above 29°C, the flame will be extinguished. The fan will run on for another 3 minutes on High before shutting down.
- If the room temperature then drops down to 26° or lower, the flame will again be lit, and then the fan will begin after the flame-on delay.

REMOTE CONTROL OPERATING GUIDE (continued)

In Auto mode, the RF thermostat will control the flame and the fan according to the programmed times and temperature. The flame can be programmed to turn on or off, or change the required temperature.

The switch off and on sequence operate as per manual operation, detailed above.

Example of Auto Operation

Set the thermostat to Monday;

Turn off at 8.00 am and set temperature of 25°C;

Lower temperature at 9.00 am with set temperature at 15°C.


- At 8.00 am on Monday, the flame will start on Low, with fan off (if flame was already off)
- After 3 minutes, the flame changes to highest setting, if room temperature is 22.5° or lower. The fan will switch on High after 3 minutes and 20 seconds after the flame was lit.
- As the temperature rises above 22.5°, the modulating valve will decrease the gas level one step for every 0.5° above 22.5°. The fan will continue to operate on High.
- When the room temperature reaches 22.5°, the modulating valve will operate at its lowest setting. The fan will switch to Low speed. The flame will remain lit as long as the room temperature is 28° or lower.
- If the room temperature were to rise above 28°, the flame will be extinguished. The fan will run for further 3 minutes on High before shutting down.
- If the room temperature then drops down to 25° or lower, the flame will again be lit, and the fan will begin after the flame-on delay.
- At 9.00 am on Monday, the required room temperature is now only 15°C.
- If the room temperature is above 18°, then the flame will be extinguished, with the fan operating for a further 3 minutes.
- If however the room temperature were to be below 18° for whatever reason, the flame would remain on together with the fan. The level of the flame, or speed of the fan, will depend how far below the 18° is the room temperature.

WARNING

When the RF thermostat is in the “Auto” mode and the room temperature drops below the minimum temperature, the fire and fan will come on and operate until the room temperature is 3° above the minimum and then turn off, therefore:

- The minimum temperature should be set at a temperature that is not likely to cause the fire to continually turn on and off.
- If leaving the house for an extended period, the RF thermostat should be turned “OFF”.
- As long as the RF thermostat is in the “Auto” mode and the temperature goes below the minimum set temperature, the fire will come on no matter what times are programmed into the thermostat.
- If you are unsure of the operation of the RF thermostat, please contact the manufacturer.

ELECTRICAL DIAGRAM





CHEMINEE PTY LTD

EMAIL sales@cheminee.com.au

WEBSITE www.Cheminee.com.au

PHONE 02 9564 2694

FAX 02 9569 8802

SHOWROOM

118 Stanmore Road, Stanmore
(Corner Wemyss St) NSW